



Variables in Turbidity Testing

Teri T. Snazelle
U.S. Geological Survey
Hydrologic Instrumentation Facility

Turbidity Basics

- Qualitative or Quantitative?
- NOT a direct measurement
- Particle size, color, and sensor configuration affect the measurement



EPA180.1 vs ISO7027

EPA 180.1

- Tungsten lamp source with color temp 2000-3000 °K
- Photodetector angle $90^\circ \pm 30^\circ$
- Aperture angle not specified
- Spectral peak response 400-600 nm

ISO 7027

- Monochromatic light source
- Photodetector angle $90^\circ \pm 2.5^\circ$
- Aperture angle 20-30°
- Spectral peak @ 860 +/- 30 nm

Turbidity Nomenclature

NTU

FBRU



FNU

FBU

AU



Turbidity NWIS PCODE

water.usgs.gov/owq/turbidity/turbidity_codes.xls


Version: May 2012

NWIS PCODE	Method Short Name	Method Source (NWQL, EPA, ASTM, Std. Meth., etc.)	Method Number	NWIS New Method Code	NWIS Old Method Code	Is Method Approved? (meets require- ments in OWQ Tech Memo 98.05)	Static / Submersible / Process	Comments	Website
NTU (Nephelometric Turbidity Units) Instruments-White or Broadband (400-680 nm) light source, 90 degree detection angle, one detector.									
63675	Chemtrac , Sensor model TruTrac, NTU	EPA	180.1	TS135	N/A	N/A	Process	For drinking water, treatment plant operations. Range 0-200 NTU	
63675	Cole-Parmer Instruments, Sensor Model EW-08391-40, NTU	EPA	180.1	TS137	N/A	N/A	Static (Portable)		http://www.colepalmer.com
63675	ConFab Instrumentation 850I, NTU	EPA	180.1	TS158	N/A	N/A	Process	In-line measurements provide instantaneous readings	
63675	ConFab Instrumentation 850S, NTU	EPA	180.1	TS159	N/A	N/A	Submersible	Sensor can be submersed to 110 foot depth	
63675	ESD, Sensor Model 800 / 800P, NTU	EPA	180.1	TS089	T	N/A	Static	Discontinued. Model 800P is portable.	
63675	Eutech Instruments, Sensor model TB1000, NTU	EPA	180.1	TS136	N/A	N/A	Static (Portable)	waterproof. Has infraRed-light version (FNU)	http://www.eutechinst.com
63675	Global Water Inst. TB 500 WL, NTU	EPA	180.1	TS160	N/A	N/A	Process		
63675	HACH, sensor model 1720 C, NTU	EPA	180.1	TS094	C	N/A	Process		
63675	HACH, sensor model 1720 D, NTU	EPA	180.1	TS095	D	N/A	Process	Submersible probe, in pipe	
63675	HACH, sensor model 1720 E, NTU	EPA	180.1	TS096	E	N/A	Process		
63675	HACH, sensor model 2100 AN (Ratio OFF), NTU	EPA	180.1	TS097	A	N/A	Static	Flow-through accessory provides more dynamic measurement, making readings more stable.	
63675	HACH, sensor model 2100 N (Ratio OFF), NTU	EPA	180.1	TS099	B	N/A	Static	Flow-through accessory provides more dynamic measurement, making readings more stable.	

Turbidity Standards



AMCO Particles




Formazin Particles

Formazin



StablCal



AMCO-Clear



Nephelometric Design




Diagram credit to Christine Kemker, Fondriest Environmental, Inc.

Nephelometric Sensors



Backscatter Design




Diagram credit to Christine Kemker, Fondriest Environmental, Inc

“Modified” ISO 7027 Nephelometric Sensor



Backscatter Sensors



Ratio Designs




Diagram credit to Christine Kemker, Fondriest Environmental, Inc


Formazin Backscatter Ratio Sensor



Formazin Backscatter Ratio Sensor




Comparable Data




USGS Techniques and Methods 3-C4


(Rasmussen and others, 2009)




Fantasy




Reality – Calibrated in Formazin/ Checked in Formazin




Reality – Calibrated in Formazin/Checked in Stablcal




Reality – Calibrated in AMCO-Clear/Checked in AMCO-Clear



Reality – Calibrated in AMCO-Clear/Checked in Formazin



Two Different 4000 NTU Standards



Things to Keep in Mind

- Differences in sensor design will cause sample measurement to vary
- No two turbidity models will give the same reading in “real” samples
- All instruments should read the actual standard value in formazin
- Polystyrene standards are sensor specific
- Instrument calibrations aren’t always accurate due to standard uncertainty

What to do?

- Don't mix turbidity standards
- Remember that turbidity is NOT a direct measurement
- Give yourself some “wiggle” room
- Verify the accuracy and the operating range after calibration
- Ask for help and BREATHE

Questions?

CHEMIST BY DAY

NINJA BY NIGHT

Teri Snazelle
(800) 382-0634 ext. 1316
tsnazelle@usgs.gov